


Pre-Tensioner Instructions



1. Place the pre-tensioner under the cable on which you plan to use it. Lift it up to the cable so the cable slips into the channel. The all-thread that extends beyond the housing should be facing the end post, with the back side of the pre-tensioner butted up to the next-to-last post/last intermediate post in the rail (not the end post itself).
2. Clamp the correctly-sized locking pliers to the cable, so the shaft beyond the thread fits into the counter-bore in the locking pliers



3. Lock the pliers.



5. You may now connect your cable at the end post, repeating the process.



4. Using a $\frac{3}{4}$ " wrench on the wrench flat of the all-thread, rotate the all-thread counter-clockwise, tightening the cable to the desired level of tension. Without having to pull tension through the entire cable, just from the pre-tensioner to the end post. When you have finished installing the cable at the end post, release the locking pliers, remove the pre-tensioner, and move on to your next cable, repeating the process.

American Structures & Design - WA | 1801 132nd Ave. E | STE 100 | Sumner, WA 98390 | P: 253-833-4343 | F: 253-833-4545
American Structures & Design - OR | 13444 NE Jarrett St. | Portland, OR 97230 | P: 971-645-4201 | F: 971-645-4212